



Blowsion

14420 Southwest Tualatin-Sherwood Road / Sherwood OR
97140 / United States
503-625-3616
blowsion.com - info@blowsion.com

INSTRUCTIONS

Part Number: **06-03-142 / 06-03-141**

Description: **Blowsion Mat Glue**

Ensure all surfaces to be bonded are clean and dry. For best results, apply at an air temperature of 70°F. Coat **both** surfaces evenly and allow them to dry before joining. Once dry, the adhesive should feel tacky but should not transfer when touched with a gloved finger. If the adhesive becomes too dry to bond, reactivate it by applying a thin, even coat.



We genuinely appreciate your business with the confidence you have placed in us, and we look forward to providing you with the best possible service in the future. Thank you for the opportunity to work with you.

