

# WORX RACING WORX COMPONENTS

Pty Ltd A.C.N. 073 435 033

1/12 Ereton Drive Labrador Queensland Australia 4215

Phone: 61 7 5537 7181 Fax: 61 7 5537 7381

## INSTALLATION INSTRUCTIONS

**PART NUMBER : WR203 WORX MAXILOADER INTAKE GRATE**

**KAWASAKI 750 SX / SXI**

**IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION**

**Tools necessary for installation:**

10mm Hex Wrench

**Parts Supplied:**

1 x Worx Intake Grate

1 x 5mm Allen Key

2 x 25mm x 6mm Allen Head Bolts

2 x 12mm x 6mm Allen Head Bolts

1. Put ski on a flat surface
  - . Roll onto left side (refer to manufacturers instructions)
  - . Remove stock intake grate using the 10mm hex wrench and wipe clean any old silicone or from hull and threaded inserts.
2. Fill threaded inserts with silicone and apply a small amount of silicone to both mounting surfaces of your new **Worx Intake Grate**.
3. Fit **Worx Intake Grate** into position using the Allen Headed bolts and Allen key supplied:  
**Important** Use the shorter (12mm) bolts in the rear mounting holes  
Failure to do this could cause damage to pump housing, tighten with Allen key supplied
4. Wipe off excess silicone with a damp cloth. Allow 4-6 hours minimum for silicone to cure before riding.
5. Regularly check that all bolts are tight on your intake grate and ride plate.

Thank you for purchasing **Worx Racing Components** Products. We firmly believe that **Worx Racing Components** Products are among the finest watercraft parts available.

A great deal of time and effort has gone into the design and development of this product to ensure that it will perform to the highest standard and that installation is a relatively straight forward and simple procedure.

If you have any questions or comments on the performance and/or installation of our products, please contact us at the above numbers.

**RIDE SAFELY PROTECT OUR ENVIROMENT  
AND RESPECT OTHERS WHO SHARE OUR WATERWAYS**