

# **WORX RACING** **WORX COMPONENTS**

Pty Ltd A.C.N. 073 435 033

1/12 Ereton Drive Labrador Queensland Australia 4215

Phone: 61 7 5537 7181 Fax: 61 7 5537 7381

## **INSTALLATION INSTRUCTIONS**

**PART NUMBER : WR207**

### **WORX MAXILOADER INTAKE GRATE SEADOO SP. SPI. SPX. XP (PRE 97)**

**IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION**

Tools necessary for installation:

10mm Hex Wrench  
Tube of clear silicone

Parts Supplied:

1 x Worx Intake Grate  
1 x 4mm Allen Key  
2 x 12mm x 6mm Socket Head Bolts  
2 x 20mm x 6mm Socket Head Bolts  
4mm Allen key

1. Put ski on a flat surface
  - . Roll onto left side (refer to manufacturers instructions)
  - . Remove stock intake grate and wipe clean any old silicone or loctite from hull and threaded inserts.
2. Fill threaded inserts with silicone and apply a small amount of silicone to both mounting surfaces of your new Worx Intake Grate.
3. Fit Worx Intake Grate into position using the Socket Headed bolts and Allen key supplied:  
**Important** Use the shorter (12mm) bolts in the rear mounting holes  
Failure to do this could cause damage to pump housing, tighten with Allen key supplied
4. Wipe off excess silicone with a damp cloth. Allow 4-6 hours minimum for silicone to cure before riding.
5. Regularly check that all bolts are tight on your intake grate and ride plate.

Thank you for purchasing **Worx Racing Components** Products. We firmly believe that **Worx Racing Components** Products are among the finest watercraft parts available.

A great deal of time and effort has gone into the design and development of this product to ensure that it will perform to the highest standard and that installation is a relatively straight forward and simple procedure.

If you have any questions or comments on the performance and/or installation of our products, please contact us at the above numbers.

**RIDE SAFELY PROTECT OUR ENVIROMENT**  
**AND RESPECT OTHERS WHO SHARE OUR WATERWAYS**