



MADANT DARSHEL PTY LTD

1/12 Ereton Drive Labrador Queensland Australia 4215

Phone: +61 7 55377181

Fax: +61 7 5537 7381

---

## INSTALLATION INSTRUCTIONS

**PART NUMBER: WR218    MAXILOADER INTAKE GRATE**  
**YAMAHA : GPR 1200 / 1300**

IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION

Tools necessary for installation:

10mm Socket Wrench

Tube of clear silicone

Parts Supplied:

1 x **Worx Intake Grate**

2 x 20mm x 6mm stainless socket head bolts

2 x 25mm x 6mm stainless socket head bolts

1 x Allen key

- 1 Remove stock intake grate and wipe clean any old silicone or loctite from mounting bolt holes and threads
- 2 Fill threads with silicone and apply silicone to the front, rear and both side mounting surfaces of your new **Worx Intake Grate**
- 3 Fit **Worx Intake Grate** into position using the new mounting bolts supplied (25mm in the front 20mm in the back).
- 4 Wipe off excess silicone with a damp cloth. Allow 4-6 hours minimum for silicone to cure before riding.
- 5 Regularly check that all bolts are tight on your intake grate and ride plate.

Thank you for purchasing **Worx Racing Components** Products. We firmly believe that **Worx Racing Components** Products are among the finest watercraft parts available.

A great deal of time and effort has gone into the design and development of this product to ensure that it will perform to the highest standard and that installation is a relatively straight forward and simple procedure.

If you have any questions or comments on the performance and/or installation of our products ,please contact us at the above numbers.

**RIDE SAFELY PROTECT OUR ENVIROMENT**  
**AND RESPECT OTHERS WHO SHARE OUR WATERWAYS**