

WORX RACING **WORX COMPONENTS**

Pty Ltd A.C.N. 073 435 033

1/12 Ereton Drive Labrador Queensland Australia 4215

Phone: 61 7 5537 7181 Fax: 61 7 5537 7381

INSTALLATION INSTRUCTIONS

PART NUMBER : WR219 WORX MAXILOADER INTAKE GRATE

KAWASAKI 2000 on STX, STX-R, STX-12F, STX- 15F

IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION

Tools necessary for installation: 1 x Small Tube of Silicone

Parts Supplied: 1 x Worx Intake Grate
1 x 5mm Allen Key

1. Remove ride plate to gain access to the two rear bolts holding the stock grate on, remove stock intake grate and wipe clean any old silicone from hull.
2. Fill threaded inserts with silicone and apply a small amount of silicone to both mounting surfaces and around the bars at the back of your new **Worx** Intake Grate where it fits up into the pump shoe.
3. Fit **Worx** Intake Grate into position using stock bolts.
4. Wipe off excess silicone with a damp cloth. Allow 4-6 hours minimum for silicone to cure before riding.
5. Regularly check that all bolts are tight on your intake grate and ride plate.

Thank you for purchasing **Worx Racing Components** Products. We firmly believe that **Worx Racing Components** Products are among the finest watercraft parts available.

A great deal of time and effort has gone into the design and development of this product to ensure that it will perform to the highest standard and that installation is a relatively straight forward and simple procedure.

If you have any questions or comments on the performance and/or installation of our products, please contact us at the above numbers.

RIDE SAFELY PROTECT OUR ENVIROMENT
AND RESPECT OTHERS WHO SHARE OUR WATERWAYS