

PART NUMBER : WR 223 WORX MAXILOADER INTAKE GRATE

SEADOO RXP

IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION

Tools necessary for installation: 10mm Socket Wrench
 13mm socket Wrench
 Tube of clear silicone

Parts Supplied: 1 x **Worx Intake Grate**

- 1 Remove stock intake grate and wipe clean any old silicone around the mounting surfaces Especially from the front because the Worx intake grate fits further forward than the OEM Intake Grate.
2. Fill threaded inserts with silicone and apply a small amount of silicone to the front mounting surface and a generous amount of silicone to the rear mounting surface and edges of your new **Worx Intake Grate**
3. Fit **Worx** Intake Grate into position using the stock mounting bolts.
- 4 Wipe off excess silicone with a damp cloth. Allow 4-6 hours minimum for silicone to cure before riding.
5. Regularly check that all bolts are tight on your intake grate and ride plate.

Thank you for purchasing **Worx Racing Components** Products. We firmly believe that **Worx Racing Components** Products are among the finest watercraft parts available.

A great deal of time and effort has gone into the design and development of this product to ensure that it will perform to the highest standard and that installation is a relatively straight forward and simple procedure.

If you have any questions or comments on the performance and/or installation of our products, please contact us at the above numbers.

RIDE SAFELY PROTECT OUR ENVIROMENT
AND RESPECT OTHERS WHO SHARE OUR WATERWAYS