

WORX RACING WORX COMPONENTS

Pty Ltd A.C.N. 073 435 033

1/12 Ereton Drive Labrador Queensland Australia 4215

Phone: 61 7 5537 7181 Fax: 61 7 5537 7381

INSTALLATION INSTRUCTIONS

PART NUMBER : WR225 WORX MAXILOADER INTAKE GRATE

KAWASAKI 800 SX-R

IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION

Parts Supplied: 1 x Worx Intake Grate
1 x 5mm Allen Key

1. Put ski on a flat surface
 - . Roll onto left side (refer to manufacturers instructions)
 - . Remove stock intake grate using Allen key supplied and wipe clean any old silicone or from hull and threaded inserts.
2. Fill threaded inserts with silicone and apply a small amount of silicone to both mounting surfaces of your new **Worx** Intake Grate.
3. Fit **Worx** Intake Grate into position using the stock Allen head bolts.
4. Wipe off excess silicone with a damp cloth. Allow 4-6 hours minimum for silicone to cure before riding.
5. Regularly check that all bolts are tight on your intake grate and ride plate.

Thank you for purchasing **Worx Racing Components** Products. We firmly believe that **Worx Racing Components** Products are among the finest watercraft parts available.

A great deal of time and effort has gone into the design and development of this product to ensure that it will perform to the highest standard and that installation is a relatively straight forward and simple procedure.

If you have any questions or comments on the performance and/or installation of our products, please contact us at the above numbers.

DON'T SETTLE FOR SECOND BEST

'Personal watercraft accessories'
FOR THE PERFORMANCE EDGE