



CESERO HOLDINGS PTY LTD

PO Box 361 Lismore NSW 2480 Australia

Phone: +61 2 6622 3126

Fax: +61 2 6621 8684

---

## INSTALLATION INSTRUCTIONS

### **PART NUMBER: WR 237 WORX INTAKE GRATE YAMAHA 2012+ FX, FX SHO**

**IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION**

Parts Supplied: **1 x Worx Intake Grate**

1. Remove stock intake grate and wipe clean any old silicone or Loctite from hull and threaded inserts.
2. Fill threaded inserts with silicone and apply a small amount of silicone to the front mounting surface and a generous amount of silicone to the rear mounting surface and edges of your new **Worx Intake Grate**
3. Fit **Worx Intake Grate** into position using the stock mounting bolts.
4. Wipe off excess silicone with a damp cloth. Allow 4-6 hours minimum for silicone to cure before riding.
5. Regularly check that all bolts are tight on your intake grate and ride plate.

It is recommended that the pump seal kit P/N **WR0703**, Silicone must be used to seal rear of intake grate to pump duct to reduce cavitation.

Thank you for purchasing **Worx Racing Components** Products. We firmly believe that **Worx Racing Components** products are among the finest watercraft parts available.

A great deal of time and effort has gone into the design and development of this product to ensure that it will perform to the highest standard and that installation is a relatively straight forward and simple procedure. If you have any questions or comments on the performance and/or installation of our products, please contact us at the above numbers.

**RIDE SAFELY PROTECT OUR ENVIROMENT  
AND RESPECT OTHERS WHO SHARE OUR WATERWAYS**