



CESRO HOLDINGS PTY LTD

PO Box 361 Lismore NSW 2480 Australia

Phone: +61 2 6622 3126 Fax: +61 2 6621 8684

WWW.WORX.COM.AU

INSTALLATION INSTRUCTIONS

PART NUMBER: **WR 238 WORX MAXILOADER INTAKE GRATE SEADOO 2012+ RXPX**

IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION

Tools necessary for installation:

13mm socket Wrench
Tube of clear silicone

Parts Supplied:

1 x **Worx Intake Grate**

- 1 Remove stock intake grate and wipe clean any old silicone or Loctite from hull and threaded inserts
2. Fill threaded inserts with silicone and apply a small amount of silicone to the front mounting surface and a generous amount of silicone to the rear mounting surface and edges of your new **Worx Intake Grate**
3. Fit **Worx Intake Grate** into position using the stock mounting bolts.
- 4 Wipe off excess silicone with a damp cloth. Allow 4-6 hours minimum for silicone to cure before riding.
5. Regularly check that all bolts are tight on your intake grate and ride plate.

Thank you for purchasing **Worx Racing Components** Products. We firmly believe that **Worx Racing Components** Products are among the finest watercraft parts available.

A great deal of time and effort has gone into the design and development of this product to ensure that it will perform to the highest standard and that installation is a relatively straight forward and simple procedure. If you have any questions or comments on the performance and/or installation of our products, please contact us at the above numbers.

**RIDE SAFELY PROTECT OUR ENVIROMENT
AND RESPECT OTHERS WHO SHARE OUR WATERWAYS**