



Cesero Holdings Pty Ltd

10 Bounty St. Lismore, NSW 2480

Phone: +61 2 6622 3126 Fax: +61 2 6621 8684

WWW.WORX.COM.AU

---

## INSTALLATION INSTRUCTIONS

### PART NUMBER : **WR242**      **WORX MAXILOADER INTAKE GRATE RICKTER**

IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION

Tools necessary for installation:

10mm Hex Wrench  
1 x 5mm Allen Key

Parts Supplied:

1 x **WORX** Intake Grate  
2 x 20mm x 6mm Allen Head Bolts  
2 x 12mm x 6mm Allen Head Bolts

- 1 . Put ski on a flat surface
  - . Roll onto left side
  - . Remove intake grate, wipe clean any old silicone from hull and threaded inserts.
2. Fill threaded inserts with silicone and apply a small amount of silicone to both mounting surfaces of your new **Worx** Intake Grate.
- 3 Fit **Worx** Intake Grate into position using the Allen Headed bolts supplied:  
**Important** Use the shorter (12mm) bolts in the rear mounting holes  
Failure to do this could cause damage to pump housing, tighten
- 4 Wipe off excess silicone with a damp cloth. Allow 4-6 hours minimum for silicone to cure before riding.
5. Regularly check that all bolts are tight on your intake grate and ride plate.

Thank you for purchasing **Worx Racing Components** Products. We firmly believe that **Worx Racing Components** Products are among the finest watercraft parts available.

A great deal of time and effort has gone into the design and development of this product to ensure that it will perform to the highest standard and that installation is a relatively straight forward and simple procedure.

If you have any questions or comments on the performance and/or installation of our products, please contact us at the above numbers.

**RIDE SAFELY PROTECT OUR ENVIROMENT  
AND RESPECT OTHERS WHO SHARE OUR WATERWAYS**