

WORX INTAKE GRATE

Part No. WR248

Suits Models:
• Kawasaki 2017+ SXR1500

Parts Supplied:

• WR248 Intake Grate

Tools Required:

• 10mm Socket

• Sikaflex

IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION

INSTALLATION INSTRUCTIONS:

1. Remove stock intake grate and clean hull of old silicone and residue
2. Apply Marine silicone sealant around front, rear mounting surfaces and edges of intake grate.
3. Fit WORX intake grate into position using OEM bolts
4. Wipe away excess sealant with cloth. Allow 24 hours for sealant to cure before riding
5. Regularly check that all bolts are tight on your intake grate.

Australia:

10B 354 Brisbane Rd Arundel QLD 4214
Phone: +61 7 5563 1031
info@worx.com.au | worx.com.au

United States:

9251 Orco Parkway Unit G, Riverside CA 92509
Phone: (951) 684-9679
info@worxracingusa.com | worxracingusa.com