

WORX RACING **WORX COMPONENTS**

Pty Ltd A.C.N. 073 435 033

1/12 Ereton Drive Labrador Queensland Australia 4215

Phone: 61 7 5537 7181 Fax: 61 7 5537 7381

INSTALLATION INSTRUCTIONS

PART NUMBER: WR308

WORX FREESTYLE RIDE PLATE YAMAHA SUPERJET

IMPORTANT : READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION

Tools necessary for installation :

10mm Hex Wrench
1 x Tube of silicone

Parts Supplied :

1 x **WORX** Ride Plate

1. Roll Ski onto left side (refer to manufacturers instructions)
Remove stock ride plate and wipe clean any old silicone from the hull and threaded inserts
2. Fill threaded inserts with silicone and apply a small amount of silicone to the mounting surfaces of your new **Worx** ride plate
3. Fit the **Worx** ride plate into position using stock bolts and tighten.
4. Apply a bead of silicone around all edges of the ride plate and smooth off before it cures.
5. Wipe off excess silicone with a damp cloth. Allow 6-6 hours for the silicone to cure before riding
- 6 Regularly check that all bolts are tight

Thank you for purchasing **Worx Racing Components** products. We believe that **Worx Racing Components** products are among the finest watercraft parts available.

A great deal of time and effort has gone into the design and development of this product to ensure that it will perform to the highest standard and that installation will be a relatively straight forward procedure. If you have any comments on the performance/or installation of our parts, please contact us on the numbers listed on page one or through your local dealer.

DON'T SETTLE FOR SECOND BEST

RIDE SAFLEY, PROTECT OUR ENVIROMENT
AND RESPECT OTHERS WHO SHARE OUR WATERWAYS