

WORX

RACING COMPONENTS

MADANT DARSHEL PTY LTD

1/12 Ereton Drive Labrador Queensland Australia 4215

Phone: +61 7 55377181

Fax: +61 7 5537 7381

INSTALLATION INSTRUCTIONS

PART NUMBER: WR 544 WORX RACE SPONSONS ALL YAMAHA SUPERJET MODELS

IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION

Tools required for installation:

Electric drill
3/16" drill bit
Blue Loctite

Parts Supplied

2 x Worx Sponsons
8 x 3/16" x 1" Allen head bolts
8 x 3/16" x 5/8" Flat Washer
3/16" drill bit
1 x Allen Key

1. Using the electric drill with the 3/16" drill bit, drill out the rear four rivets holding on the side and rear mouldings, clean out the holes in the hull. Drill holes in the Worx sponsons to correspond with the holes now in the hull. If there are no rivets in the hull drill holes equidistant from each other starting at the rear hole provided in the Worx sponson as a guide. This hole should line up with the last rivet in the hull.
2. Fit the Worx sponsons using the 8 x 3/16" x 1 Allen head bolts and the flat washers. Apply a small amount of the blue loctite to each bolt. Be careful to start all of the bolts into the sponsons before you tighten using the Allen key supplied



Worx Sponsons fitted